



- 1.Low battery may result in a malfunction of the terminal. Before using PDA for the first time, charge the battery for at least 8 hours.
- 2.Connect the USB connector to a power outlet using the included AC adapter & Cable. (Do not plug or pull the USB connector violently to avoid damage)

1




1.SIM Card Slot	2.Left Scan Key
3.USB Connector	4.Cradle Connector
5.Main Microphone	6.Keypad
7.Virtual Keypad	8.Screen
9.Light/ Proximity Sensor	10.Earpiece
11.LED	12.Front Camera (Optional)

2




13.Scan Window	14.Speaker
15.Power Key	16.Right Scan Key
17.Battery Cover	18.Battery Cover Latch
19.Lanyard Hole	20.Sec. Microphone
21.Rear Camera	22.Flashlight

3



- 1.Hold down the Power key for 5 seconds and then tap "Power off" to turn off the terminal. Unlock the battery cover latch and remove the cover.
- 2.Remove the battery.

7



- 1.Pull the tray out from the Micro SD/SIM card slot.
- 2.Insert the Micro SD/SIM card into the corresponding slot on the tray, with its metal contacts facing down. Then gently push the tray into the slot until it locks in place.


8

Adjust the scan angle and the distance between the PDA and the target barcode to make them fall into the following ranges:

- 1.Point the device focus lamp at the center of the barcode.
- 2.Move the device until you find the appropriate scan distance.


3.Optimum scan angles:

- Skew (α) < 45° (0° preferably)
- Pitch (γ) < 45° (5°- 20°preferably)
- Roll (β) = 0°- 360°



9

Key




1.Arrow Shortcut Key	2.Number Key
3.Backspace Key	4.Alphanumeric Key
5.Main Scan Key	6.Fn Key
7.Enter Key	8.Volume Shortcut Key
9.User-Defined Key	

*Shortcut Key Usage: Press the Fn key and then shortcut key to activate the function.

4


LED Status



Scan/Decode	
Blue LED flashes once	Decode successfully
Charging /Battery Status	
Green LED on	Fully charged
Red LED on	Charging in progress
Red LED flashes	Low-battery alert

5

Installing the Battery



- 1.Unlock the battery cover latch as shown in the figure above and then remove the cover.
- 2.Insert the battery as indicated into the battery compartment, with its metal contacts facing down and lining up with the metal contacts on the inside of the terminal.

6

Safety Guidelines

- 1.Do not charge in direct sunlight or humid environment. If the AC adapter is faulty, please replace it with a new one recommended by the manufacturer.
- 2.Don't dispose of batteries in a fire or make them short-circuit, or they may explode. Please use the battery recommended by the manufacturer.
- 3.Do not use the terminal's wireless functionalities where wireless device use is prohibited or where it may cause interference or danger, such as in aircrafts, petrol stations.
- 4.If the terminal cannot be switched on after experiencing a sudden or unexpected power loss or other abnormalities, remove and then reinstall its battery to reset the terminal.
- 5.Do not throw, drop or strike the terminal. Doing so may damage the LCD display, interrupt running programs, cause data loss in memory and result in malfunction.
- 6.Clean the scan window regularly. Do not touch it with hands. Scratched or smudged window may degrade reading performance.
- 7.Use only a dry soft cloth to clean the terminal. Cleaning it with wet cloth or benzene/thinner/other volatile chemicals may deform and shorten the service life of the keypad and shell of the terminal.
- 8.Do not place the terminal face down on any surface, or there might be misoperations.
- 9.Sudden temperature drops may cause condensation on the shell which could cause malfunction. Care should be taken to avoid condensation. If condensation occurs, dry the terminal before use.

10


More Information



For more information, please visit the Newland website at <http://www.newlandaidc.com>

PN:1060090540

11



Quick Start